



Scan to view Product Instructional Video or visit:
<http://www.creativedisplaysite.com/superstrong.html>



Product Parts


- 1 - Frame
- 2 - Chain
- 3 - Tabs
- 4 - Graphic Ledge



Sign Install and Display Set-Up


Step 1

Carry the A-Frame (1) to the desired location. Separate the front and back segments of the A-Frame (1) until the Chain (3) is taut.



Step 2

Slide the graphic in behind Tabs (3) until the graphic rests on the Graphic Ledge (4). Repeat to add a graphic to the other side.



Storage

Store in a cool dry location.

Care

To clean, wipe with damp cloth.

Warranty Information: All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.